AVO-IPJP2KD-ENC Tesira Command Sheet

For Tesira Command String blocks · Version 1.1.0

Every command for one AVO-IPJP2KD-ENC, as fixed strings for Tesira Command String blocks. It controls the AVO-IPJP2KD-ENC through its AVO-IPCTL-JP2K controller, on the controller's control port (Telnet 23). Connect it to the controller's address; the AVO-IPJP2KD-ENC is named by its encoder number in the controller's list. No other KanexPro software is needed. The same strings are in `KanexPro-AVO-IPJP2KD-ENC-Tesira-Command-Sheet-1.1.0.csv` for copying.

Before you start — the Tesira server must reach the AVO-IPCTL-JP2K's CTRL port on TCP 23. Give the controller a fixed IP address (or a DHCP reservation), and note this AVO-IPJP2KD-ENC's encoder number in its list.

TABLE OF CONTENTS

1. Connection
2. Commands
3. Reading it back
4. Troubleshooting

1. CONNECTION

HOW THE STRINGS ARE SENT	
Transport	TCP, port 23, to the AVO-IPCTL-JP2K's address (its CTRL port). Port 23 is the AVO-IPCTL-JP2K's Telnet control port; Telnet must be on in its own page (it is as shipped).
{n}	this AVO-IPJP2KD-ENC's encoder number in the AVO-IPCTL-JP2K's list: put it in place of {n} in every string.
Line ending	CR LF (hex 0D 0A), after every string.
On connect	the controller first sends a few Telnet option bytes and a welcome text, then its prompt (a word ending in >). Ignore them.
Answers	the controller repeats each string, then answers [SUCCESS] or [ERROR] and why, then its prompt. Wait for the prompt before the next string.

2. COMMANDS

3 strings, and a template for each list too long to write out. The Bytes column is for encoder number 1.

#	Command	String	Bytes (hex, with the line ending)
1	**Encoder: Show on decoder = {decoder} (1 to 64)**	`SET DEC {decoder} SWITCH {n} ALL`	`the number in place of {decoder}`
2	**Encoder: Show on decoder = Decoder 1**	`SET DEC 1 SWITCH {n} ALL`	`53 45 54 20 44 45 43 20 31 20 53 57 49 54 43 48 20 31 20 41 4C 4C 0D 0A`
3	**Encoder: Show on decoder = Decoder 33**	`SET DEC 33 SWITCH {n} ALL`	`53 45 54 20 44 45 43 20 33 33 20 53 57 49 54 43 48 20 31 20 41 4C 4C 0D 0A`
4	**Encoder: Show on decoder = Decoder 64**	`SET DEC 64 SWITCH {n} ALL`	`53 45 54 20 44 45 43 20 36 34 20 53 57 49 54 43 48 20 31 20 41 4C 4C 0D 0A`

3. READING IT BACK

Send this to read the controller back (on a timer, or after a change).

#	String	Bytes (hex)	The reply gives
1	`GET STATUS`	`47 45 54 20 53 54 41 54 55 53 0D 0A`	Online, Picture in: the encoder and decoder tables, one row per box by its 3-digit number (a decoder's row names the encoder it shows)

Installer settings (streams, I/O ports, layouts, the network, logins and firmware) stay on the AVO-IPCTL-JP2K's own page.

4. TROUBLESHOOTING

Nothing happens.
Check the AVO-IPCTL-JP2K's address and that TCP 23 is open from the Tesira server to it, and that Telnet is on in the AVO-IPCTL-JP2K's own page at port 23.

It answers [ERROR].
The value names something not in the AVO-IPCTL-JP2K's list, or {n} is not this AVO-IPJP2KD-ENC's encoder number.