AVO-IPJP2KWPM Control4 Driver Guide

For Composer Pro · Driver version 1.1.0

The KanexPro AVO-IPJP2KWPM driver lets a Control4 system control one AVO-IPJP2KWPM. It controls the AVO-IPJP2KWPM through its AVO-IPCTL-JP2K controller, on the controller's control port (Telnet 23). Connect it to the controller's address; the AVO-IPJP2KWPM is named by its encoder number in the controller's list. No other KanexPro software is needed. Each control is a programming command, and each reading is a variable that follows changes made on the AVO-IPCTL-JP2K's own page or by another system.

Before you start — the Control4 controller must reach the AVO-IPCTL-JP2K's CTRL port on TCP 23, and Telnet must be on in the AVO-IPCTL-JP2K's own page (it is as shipped).

TABLE OF CONTENTS

1. Install the driver
2. Properties
3. Programming commands
4. Variables
5. Troubleshooting

1. INSTALL THE DRIVER

1. Download **KanexPro-AVO-IPJP2KWPM-C4-1.1.0.zip** from the AVO-IPJP2KWPM page on kanexpro.com (Resources) and unzip it.
2. In Composer Pro, add the driver from the file `KanexPro-AVO-IPJP2KWPM-C4.c4z` (Driver > Add or Update Driver, or drag the file in).
3. Add it to the project in the room where the unit is.
4. Select it and set its properties (section 2). **Connection** shows Connected once it reaches the unit.

One driver per unit — for two AVO-IPJP2KWPM units, add the driver twice and give each its own encoder number.

2. PROPERTIES

DRIVER PROPERTIES	
IP Address	The AVO-IPCTL-JP2K's address on the control network (its CTRL port). Empty by default.
Port	23 (Telnet), the AVO-IPCTL-JP2K's control port. Leave it unless the controller's own page moves it. Default 23.
Encoder Number	This AVO-IPJP2KWPM's encoder number in the AVO-IPCTL-JP2K's list (its own page, or GET STATUS). Default 1.
Poll Interval	How often it reads the controller back (0 = only after a change). Default 10 s.
Debug Mode	On prints every command and reply to the Lua output.
Connection	Read only: Connected, Connecting, Not connected (and why), Refused (and which command), or what to set.
Driver Version	Read only: 1.1.0.

Action: **Reconnect** connects again at once.

3. PROGRAMMING COMMANDS

1 commands. Use them in Composer's Programming view, from any event.

#	Command	Parameters	What it does

1	**Show on decoder**	Decoder (a list: Decoder 1, Decoder 2, Decoder 3, Decoder 4 ...)	Sets the show on decoder. Choices: Decoder 1; Decoder 2; Decoder 3; Decoder 4; Decoder 5, and 59 more.

4. VARIABLES

`STATUS` is the Connection text. The others follow the unit, whoever changes it:

#	Variable	Kind	What it holds
1	`ONLINE`	on/off	Readings Online
2	`SIGNAL`	on/off	Readings Picture in

5. TROUBLESHOOTING

Connection says Not connected.
Check the IP Address property against the AVO-IPCTL-JP2K's CTRL port address (its own page or front panel), and that TCP port 23 is open from the Control4 controller to it. Telnet must be on in the AVO-IPCTL-JP2K's own page, at port 23.

It controls the wrong box, or none.
Check the Encoder Number property: it is the encoder's number in the AVO-IPCTL-JP2K's list, not its IP address.

Connection says Refused, and names a command.
The AVO-IPCTL-JP2K refused that change, for example a number that is not in its list.

Changes made elsewhere do not show in Control4.
Set Poll Interval above 0. Changes made on the AVO-IPCTL-JP2K's own page or by another system then show in the variables within that many seconds.

I need to see what the driver sends.
Set Debug Mode to On: the Lua output in Composer shows every command sent and every reply.